

Panasonic DBS – System Time Change

To change the time on your Panasonic DBS system, follow the instructions below:

1. The time must be changed from extension 200
2. Leaving the handset down, press the on/off key, followed by recall, followed by the # key
3. Dial 3, then enter 4 digits for the current date and month, followed by four digits for the year
4. Having entered the date, now enter the time in 24 hour format, pressing the on/off key to finish