

## **Panasonic KXT 308 and 616 – System Time Change**

To change the time on your Panasonic KXT 308 and 616 systems, follow the instructions below:

1. The time must be changed from extension 21 only
2. So from extension 21, leaving the handset down, press the key marked intercom or ICM depending on the model of your phone and then dial 77
3. Enter the time in 12 hour format, followed by either 0 for AM or 1 for PM
4. Press the # key to finish