

Panasonic VP50, 100, 200 Voice Processor – System Time Change

To change the time on your Panasonic voicemail systems, follow the instructions below:

1. The time within the Voice Processing System can be reprogrammed from any extension.
2. Firstly access the voicemail, for example on the KXTD you would dial 265.
3. Dial #6, followed by *998
4. Dial 4 to set the time and date
5. Dial 1 to change the current setting
6. Enter the current time and press #
7. Enter 1 for AM or 2 for PM
8. Press 2 to accept
9. Press 1 to change the current setting. This will change the date.
10. Enter the month and press #
11. Enter the day and press #
12. Enter the last 2 digits of the year and press #
13. Press 2 to accept