

## **Toshiba DK 40, DK280, CT – System Time Change**

To change the time on your Toshiba system, follow the instructions below:

It is only possible to adjust the systems time from the operators' telephone – usually extension 200.

To confirm that the extension is the operators, dial "Spkr #402"

You should see on your display: PHY=000 LOG=000

1. Place the handset on hook
2. Press the internal (INT) button and dial #652
3. Dial the time (HHMMSS)  
Dial hour / minute /second in the 24 hour clock format HHMMSS  
Enter a leading 0 for any single digit entered
4. Press the REDIAL button – you will hear a confirmation tone
5. Press the Spkr button – the telephone will return to the idle mode after you press the button